

ADJUSTABLE PRESSURE RELIEF VALVE



The vehicle it will be applied should be completely hermetical (air tight).

Toxic air is filtrated by highly protected filters and filtered clean air is blown into the vehicle.

The pressure in the vehicle increases until balancing valve is opened with continuous air flow.

Pressure level is kept fixed, blown extra air is discharged from air pressure balancing valve.

The pressure created by clean air within the vehicle, prevents toxic air to penetrate inside from outside the vehicle and protection is ensured.

MIL-STD-810 High temperature	MIL-STD-810 Low temperature	MIL-STD-810 Humidity Test	MIL-STD-810 Corrosion Test	MIL-STD-810 Shock Vibration
------------------------------	-----------------------------	---------------------------	----------------------------	-----------------------------

DIMENSIONS

Weight: 0.60 kg
Width: 86mm
Length: 86mm
Height: 75mm

COLOURS

 RAL6071
  RAL6019
  FS 33245
  RAL 9010
  RAL 6031